

Premier G7 MB Client

- * Windows 10/11
- * iPad, iPhone & Android Phone

Direct Mode
[Version 1.0.6]

- G7-BS, G7-BSR base station
- X7-BS base station extender
- G7-T2/TX wireless temperature sensor
- G7-H2/H3 wireless temperature humidity sensor
- G7-AD wireless analog sensor
- G7-D2 wireless digital alarm
- G7-TP wireless temperature pressure sensor
- G7-MB wireless Modbus sensor




Contents

1. Overview.....	3
2. Download “G7 MB Client” App from Microsoft Store	4
3. Registration	5
4. Network & Login	6
5. Main Screen.....	10
6. Meter View	12
7. Meter Alarm View	22
8. Sensor Activated / Deactivated	24
9. HMI (Human Machine Interface) Data View	26
10. HMI Alarm View	28
11. Dashboard Data View	29
12. Dashboard Alarm View	31
13. Compare Chart	33
14. Report – History Data.....	36
15. Day Night Display	42
16. Data Export.....	43
17. Alarm Type	45
18. How user is alerted by alarm?	51
19. System Setting.....	54
20. G7 Viewer	58
21. G7 Client for Android Phone.....	61
22. G7 Client for iPhone	66
23. G7 Client for iPad	71
24. Safety and Regulatory Notice	75
25. Manufacturer’s Disclaimer Statement	76

1. Overview


(1) G7 MB Client - Server Mode

- * Data is transmitted to Base Station from wireless sensor
- * Base Station uploads data to Server over LAN or Internet
- * G7 Client app receives data from Server over LAN or Internet




(2) G7 MB Client - Direct Mode

- * Data is transmitted to Base Station from wireless sensor
- * Base Station uploads data to G7 Client app over LAN or Internet directly



2. Download “G7 MB Client” App from Microsoft Store

Search “G7 MB Client” in keywords, and click [Get] to install



Install “G7 Client for iPad” and “G7 Client for iPhone” from App Store

Install “G7 Client for Android Phone” from Play Store or apk file

(1) Configuration parameters

- All settings in following pages are applied to the selected base station.
- Each base station has its own setting in display view and alarm.
- All settings are stored in locally.

(2) Log Off is necessary only when port is changed.

(3) G7 MB Client Lite [Direct Mode] - Free


- One single client receives data from max. 2 base stations simultaneously

(4) G7 MB Client Licensed [Direct Mode] - Paid

- One single client receives data from max. 20 base stations simultaneously


3. Registration

(1) Open [G7 MB Client], Click Registration [] icon



(2) [Product Key] must be the same to that of base station


* License Key is NOT necessary for free lite version.




4. Network & Login

(i) DO NOT run G7 Setup Software, G7 Centre Software and G7 Client App simultaneously.

(A) IP over LAN




❖ Base Station




❖ G7 MB Client [Direct Mode]


Enable [Auto] for auto login



(B) IP over Internet




❖ Base Station




❖ Router #2: Port Forwarding

Port Forwarding List (Max Limit : 32)				
Service Name	Port Range	Local IP	Local Port	Protocol
G7 Client direct mode	6900	192.168.2.70		TCP




❖ G7 MB Client [Direct Mode]

(C) DDNS over Internet




❖ Base Station



❖ Router #2: Port Forwarding


Port Forwarding List (Max Limit : 32)				
Service Name	Port Range	Local IP	Local Port	Protocol
G7 Client direct mode	6900	192.168.2.70		TCP

❖ G7 MB Client [Direct Mode]




(D) Firewall Setting

Enable Firewall on both private and public network




Allow G7 MB Client app on both private and public network




5. Main Screen

(1) Main Screen after login




Please wait! Station ID will be displayed automatically upon successful connection and data update.



(2) Select the base station

Other Station ID will be available for selection upon successful connection and data update.



(3) Configuration parameters

- All settings in following pages will only be applied to the selected base station.
- Each base station has its own setting in display view and alarm.
- All settings configured is applied in local computer only


(4) Log Off is necessary only when port is changed.


(5) Direct Mode

- Each base station sends data to one client only
- G7 MB Client Lite for Win10 & iPad supports max. 2 base stations simultaneously
- G7 MB Client for Win10 & iPad (Full Version) supports max. 20 base stations simultaneously
 - * license is needed
- G7 MB Client for iPhone, Android Phone supports max. 20 base stations simultaneously
 - * no license is needed

6. Meter View

Once data from new base stations arrives, Station ID will be displayed automatically.
Live sensor reading is displayed.





- 1) Delete Station ID
- 2) Modify Station Name
- 3) Setup Alarm Alert Properties
- 4) Start Automatic Page Jump of groups in selected base station



Mouse Left Click: Start Automatic Page Jump of all base stations
Jump interval can be changed on [System Setting]



Mouse Left Click: Day / Night Screen Display Selection
Mouse Right Click: Day Time Adjustment



Mouse Left Click: Screenshot Capture



Mouse Left Click: °C / °F Selection [temperature unit] model: G7-T2/H2 →



Mouse Left Click: psi / MPa Selection [pressure unit] model: G7-TP →



Mouse Left Click: Enable / Disable Audio Alarm Buzzer



Mouse Left Click: Acknowledge All Alarms displayed in the list on bottom of screen

Dark Grey Background:

Group of sensors on display




Number in Red:
Group with triggered alarm sensors

Red Line:
Group with activated sensors

Without Red Line:
Group without activated sensors

A) Alarm Setup

- 1) Select Sensor – Left Mouse Click on left side, it will be enlarged and displayed on right side
- 2) Activate Alarm Setup – Double Click Left Mouse Button of selected sensor on right side
- 3) Click on the alarm level line, and drag to change the alarm level
- 4) Beside point and drag the alarm level line, alarm level can be setup by click [] button
- 5) Click [] to save setting into local computer



User will be alerted by G7 MB Client Software and alarm email for the following alarm types:

- Wireless Sensor Communication Loss
- Sensor Probe Disconnected or Defect
- Sensor Battery Low Level [default: 2.5V]
- Channel A - Temperature / Analog Sensor A01 High Low Alarm
- Channel H - Humidity / Analog Sensor A02 High Low Alarm
- Digital Alarm D01, D02
- Device Alarm

B) Display Range & Alarm Level Setup

- (1) Double Left Click Mouse on main screen, or
- (2) Click [] icon to start setting
- (3) Click [] icon to save setting




Max. Value

It is the max value to be displayed, but NOT
the max value of sensor measuring range.


Min. Value

It is the min value to be displayed, but NOT
the min value of sensor measuring range.


■ G7-T2/H2 Wireless Temperature & Humidity Sensor




■ G7-D2 Wireless Digital Alarm




■ G7-AD Wireless Analog Sensor (AD01: 4-20mA signal)




■ G7-AD Wireless Analog Sensor (AD02: 0-5VDC signal)



■ G7-TP Wireless Temperature & Pressure Sensor




■ G7-MB Wireless Modbus Sensor




C) Alarm Email Address

Once soft alarm is triggered, alarm email will be delivered to preset email address.

(1) Click [Menu] icon > [System] > [E-mail Setup]





(2) Enter [Email Server], [Alarm Email Recipient Address], and Click [Save]





D) Alert Interval & Alarm Delay

- (1) Display and Email Alert will not be repeated within [Alert Interval] even when there is new alarm.
- (2) When alarm level is triggered, alarm will be activated only after [Alarm Delay] time.
- (3) Click [] icon > Display Alert Interval, Email Alert Interval and Alarm Delay Time




E) Station Name & UTC Time Zone

- (1) Click [] icon to modify the station name and UTC time zone
- (2) UTC is the location time zone of base station




7. Meter Alarm View

(1) Display Alert on alarm triggered




(2) Left Mouse Click to acknowledge each sensor alarm.




(3) Mouse Click to acknowledge each sensor alarm.

When alarm is triggered, user will be alerted by:

- Screen Display
- Audio Buzzer
- Alarm Email or SMS



- * Click on each sensor to acknowledge the selected sensor alarm.
- * Click [] button to acknowledge all sensors alarm.
- * Once acknowledged, alert will only be repeated after “Alert Interval”.




8. Sensor Activated / Deactivated

Number of wireless sensors will be automatically detected by G7 MB Client.

Activate/Deactivate individual sensor to avoid false alarm when user adds/disconnects any sensor later.

This setting is done in G7 MB Client [HMI page].




If sensor is not connected but activated, it will cause many false alarms.

In this example, sensors S12~S16 is not connected causing alarms.


User should deactivate those sensors by Right Mouse Click S12~S16 icons.

Click [Save Configuration] in HMI mode.




Sensor Health Status Real Time Monitoring

Enable “Wireless Sensor Disconnection Alarm” will allow Client Software keep checking the communication status of each sensor.





When sensor S02 is activated but not configured properly, Client Software will alert user as below.

If S02 is disconnected, user should deactivate S02 to avoid false alarm.




9. HMI (Human Machine Interface) Data View

In HMI mode, Mouse Right Click on main screen to load the background picture in png file format.



Select and locate sensors on HMI display:



Select sensor to be displayed on picture

- * Mouse Left Click to select or deselect the sensor
- * **Point & Drag** to any location on the picture
- * Sensor Number box is dark grey when it is placed on picture
- * Sensor Number box is light grey with red bar when it is available for selection
- * Point and Click the dark grey box will remove it from the picture


01 Sensor activated and selected for display on HMI

06 Sensor activated – available for display on HMI

15 Sensor deactivated – not available for display on HMI

10. HMI Alarm View

Alarm Level should be setup on METER view.



When alarm is acknowledged, this sensor alarm will only be active again after “Display Alert Interval”.

11. Dashboard Data View

Select the Base Station

Select data to be displayed – sensor data, battery voltage level

1) Sensor Data View

Temperature or Analog Sensor

Temperature Humidity Sensor

Digital Alarm

Mouse Right Click: Modify Sensor Name

[Direct Mode] - G7 MB Client

Meter HMI Data Compare Report

25.89 57.46 25.62 24.43 S01 - TH sensor S02 - TEMP1 S03 - TEMP2 S04 - SWITCH S05 - TEMP3 S06 - analog sens S07 - water level S08 - TP Sensor

24.43 24.68 25.00 24.93 24.07 72.31 24.79 62.28 24.00 62.10 24.40 62.20

S09 - 09 S10 - 10 S11 - 11 S12 - 12 S13 - 13 S14 - 14 S15 - 15 S16 - 16

S17 - 17 S18 - 18 S19 - 19 S20 - 20 S21 - 21 S22 - 22 S23 - 23 S24 - 24

S25 - 25 S26 - 26 S27 - 27 S28 - 28 S29 - 29 S30 - 30 S31 - 31 S32 - 32

S33 - 33 S34 - 34 S35 - 35 S36 - 36 S37 - 37 S38 - 38 S39 - 39 S40 - 40

S41 - 41 S42 - 42 S43 - 43 S44 - 44 S45 - 45 S46 - 46 S47 - 47 S48 - 48

S49 - 49 S50 - 50 S51 - 51 S52 - 52 S53 - 53 S54 - 54 S55 - 55 S56 - 56

S57 - 57 S58 - 58 S59 - 59 S60 - 60 S61 - 61 S62 - 62 S63 - 63 S64 - 64

Sensor Battery

Base Station 00022 - machine room

Soft Alarm 2022-03-01 15:37:00 Station: 00006 - storage S05 - 05, Alarm Type: Low Battery, Low Level Alarm: 1.080 lower than 2.500

Soft Alarm 2022-03-01 15:33:00 Station: 00006 - storage S05 - 05, Alarm Type: Low Battery, Low Level Alarm: 1.080 lower than 2.500

2022-03-01 15:43:00


Select the Base Station

Select reading to be displayed

- * Sensor Data
- * Battery Voltage Level

2) Battery Level View

- Battery Voltage Level Display
- Voltage Alarm Level Setup



Battery Voltage Level

Mouse Left Click:

- * Setup alarm voltage level of selected sensor
- * Default: 2.8V

[Direct Mode] - G7 MB Client

Meter	HMI	Data	Compare	Report				
3.640 S01 - TH sensor	3.650 S02 - temp	3.650 S03 - TEMP2	3.650 S04 - SWITCH	3.660 S05 - TEMP3	3.660 S06 - analog sens	3.640 S07 - water level	3.610 S08 - TP Sensor	
3.630 S09 - refrigerator	3.610 S10 - 10	3.640 S11 - 11	3.630 S12 - 12	3.640 S13 - 13	3.660 S14 - 14	3.630 S15 - 15	3.650 S16 - 16	
S17 - 17	S18 - 18	S19 - 19	S20 - 20	S21 - 21	S22 - 22	S23 - 23	S24 - 24	
S25 - 25	S26 - 26	S27 - 27	S28 - 28	S29 - 29	S30 - 30	S31 - 31	S32 - 32	
S33 - 33	S34 - 34	S35 - 35	S36 - 36	S37 - 37	S38 - 38	S39 - 39	S40 - 40	
S41 - 41	S42 - 42	S43 - 43	S44 - 44	S45 - 45	S46 - 46	S47 - 47	S48 - 48	
S49 - 49	S50 - 50	S51 - 51	S52 - 52	S53 - 53	S54 - 54	S55 - 55	S56 - 56	
S57 - 57	S58 - 58	S59 - 59	S60 - 60	S61 - 61	S62 - 62	S63 - 63	S64 - 64	

Sensor Battery

Base Station: 00022 - machine room 2022-03-04 13:52:00

Soft Alarm 2022-03-04 13:34:00 Station: 00006 - meter S05 - 05, Alarm Type: Low Battery, Low Level Alarm: 1.070 lower than 2.500

Soft Alarm 2022-03-04 13:22:00 Station: 00022 - machine room S08 - TP Sensor, Alarm Type: Low Pressure Alarm, Low Level 2 Alarm: 0.000 lower than 10.000


Select the Base Station

Select reading to be displayed

- * Sensor Data
- * Battery Voltage Level

Mouse Right Click:

- * Setup alarm voltage level of **All** Sensors



12. Dashboard Alarm View

1) Sensor Alarm View

Alarm Level should be setup on METER view.

Alarm Non-acknowledged: Red Background Box
Mouse Left Click to acknowledge alarm

Green:Normal Data

Digital Alarm

- * Red: Closed (Alarm)
- * Green: Open

Alarm Acknowledged

- * Green: Normal
- * Red: High Alarm
- * Yellow: Low Alarm

Base Station		00022 - machine room	2022-03-03 16:46:00
Soft Alarm	2022-03-03 16:44:00	Station: 00022 - machine room	S08 - TP Sensor, Alarm Type: Low Pressure Alarm, Low Level 1 Alarm: 14.070 lower than 15.000
Soft Alarm	2022-03-03 16:43:00	Station: 00022 - machine room	S09 - 09, Alarm Type: Low Temperature, Low Level 2 Alarm: -23.00 lower than -20.00
Soft Alarm	2022-03-03 16:39:00	Station: 00022 - machine room	S07 - water level, Alarm Type: Low Level, Low Level 1 Alarm: 0.1940 lower than 0.2000

Alarm List Display
Mouse Right Click – display the list of 99 newest alarms

When alarm is acknowledged, this sensor alarm will only be active again after “Display Alert Interval”.

2) Battery Level Alarm View

Battery Alarm Level can be setup by mouse right click.

Alarm Acknowledged

* Yellow: Low Alarm

Alarm Non-acknowledged: Red Background Box

Mouse Left Click to acknowledge alarm

Green: Normal Voltage



Alarm List Display

Mouse Right Click – display the list of 99 newest alarms

Select reading to be displayed

* Sensor Data


* Battery Voltage Level

13. Compare Chart

(1) Live Chart View

- Select the Base Station and Sensor Group or Individual Sensor
- Each Base Station supports max. 64 sensors in 8 groups.
- Sensors are grouped as 01~08, 09~16, 17~24, 25~32, 33~40, 41~48, 49~56, 57~64.
- Timeline is fixed in displaying the most updated ~100 data readings
- Mouse over each point will display the reading at that time

Statistic Data: Average, Max. & Min. Values in the selected period are displayed



Select sensor group to be displayed in line chart

* Mouse Left Click to select the sensor group

Mouse Left Click

select or deselect the sensor to be displayed in line chart

Hide Sensor Menu

18

Sensor activated and selected for display in line chart

12

Sensor activated – available for display in line chart


25

Sensor deactivated – not available for display in line chart

(2) Channel A, H

- Channel A > displays temperature, AD1, or D01 according to sensor type
- Channel H > displays humidity, AD2, or D02 according to sensor type



Channel	G7-T2/TX/H2/H3	G7-AD	G7-TP	G7-MB	G7-D2
A	Temperature	AD1: 4-20mA	Temperature	Floating Point	D01: Open/Close
H	Humidity	AD2: 0-5V	Pressure	Integer	D02: Open/Close



High & Low Alarm Level lines can be dragged to different values for comparison or reference.

(3) Chart Line and Column Graph


- When only one sensor is selected, Chart Line and Column Graph can be selected.



14. Report – History Data

(1) History Data Chart View

- Select the Base Station and Sensor Group or Individual Sensor
- Each Base Station supports max. 64 sensors in 8 groups.
- Sensors are grouped as 01~08, 09~16, 17~24, 25~32, 33~40, 41~48, 49~56, 57~64.
- Select period of history data (Year, Month, Week, Day, Hour)
- Mouse over each point will display the reading at that time



Select sensor group to be displayed in line chart

- * Mouse Left Click to select the sensor group

select or deselect the sensor to be displayed in line chart

Hide Sensor Menu

18 Sensor activated and selected for display in line chart

12 Sensor activated – available for display in line chart

25 Sensor deactivated – not available for display in line chart

(2) History Data Period & Data Storage

- Incoming data of all connected base stations will be saved locally
- Select time range and start time for history data display

Select Time Period
Year/Month/Week/Day/Hour

Select Start Date/Time

Show/Hide Time Menu

[Direct Mode] - G7 MB Client

Meter HMI Data Compare Report

Year Month Week Day Hour

Station Name: 00040 - Data centre

2010 2011 2012 2013 2014 2015 2016 2017 2018 2019 2020 2021 2022 2023

2010-01-01 - 2023-08-08

2010-01-01 2010-02-01 2010-03-01 2010-04-01 2010-05-01 2010-06-01 2010-07-01 2010-08-01 2010-09-01 2010-10-01 2010-11-01 2010-12-01 2011-01-01 2011-02-01 2011-03-01 2011-04-01 2011-05-01 2011-06-01 2011-07-01 2011-08-01 2011-09-01 2011-10-01 2011-11-01 2011-12-01 2012-01-01 2012-02-01 2012-03-01 2012-04-01 2012-05-01 2012-06-01 2012-07-01 2012-08-01 2012-09-01 2012-10-01 2012-11-01 2012-12-01 2013-01-01 2013-02-01 2013-03-01 2013-04-01 2013-05-01 2013-06-01 2013-07-01 2013-08-01 2013-09-01 2013-10-01 2013-11-01 2013-12-01 2014-01-01 2014-02-01 2014-03-01 2014-04-01 2014-05-01 2014-06-01 2014-07-01 2014-08-01 2014-09-01 2014-10-01 2014-11-01 2014-12-01 2015-01-01 2015-02-01 2015-03-01 2015-04-01 2015-05-01 2015-06-01 2015-07-01 2015-08-01 2015-09-01 2015-10-01 2015-11-01 2015-12-01 2016-01-01 2016-02-01 2016-03-01 2016-04-01 2016-05-01 2016-06-01 2016-07-01 2016-08-01 2016-09-01 2016-10-01 2016-11-01 2016-12-01 2017-01-01 2017-02-01 2017-03-01 2017-04-01 2017-05-01 2017-06-01 2017-07-01 2017-08-01 2017-09-01 2017-10-01 2017-11-01 2017-12-01 2018-01-01 2018-02-01 2018-03-01 2018-04-01 2018-05-01 2018-06-01 2018-07-01 2018-08-01 2018-09-01 2018-10-01 2018-11-01 2018-12-01 2019-01-01 2019-02-01 2019-03-01 2019-04-01 2019-05-01 2019-06-01 2019-07-01 2019-08-01 2019-09-01 2019-10-01 2019-11-01 2019-12-01 2020-01-01 2020-02-01 2020-03-01 2020-04-01 2020-05-01 2020-06-01 2020-07-01 2020-08-01 2020-09-01 2020-10-01 2020-11-01 2020-12-01 2021-01-01 2021-02-01 2021-03-01 2021-04-01 2021-05-01 2021-06-01 2021-07-01 2021-08-01 2021-09-01 2021-10-01 2021-11-01 2021-12-01 2022-01-01 2022-02-01 2022-03-01 2022-04-01 2022-05-01 2022-06-01 2022-07-01 2022-08-01 2022-09-01 2022-10-01 2022-11-01 2022-12-01 2023-01-01 2023-02-01 2023-03-01 2023-04-01 2023-05-01 2023-06-01 2023-07-01 2023-08-01

27.474
27.14
25.14
23.14
21.14
20.808
19.14

00:00 04:00 08:00 12:00 16:00 20:00

Base Station 00040 - Data centre

Soft Alarm 2022-03-07 13:18:00 Station: 00022 - machine room S07 - water level; Alarm Type: Low Level, Low Level 1 Alarm: 0.1990 lower than 0.2000

Max. 2 years data will be saved into local storage.


Click [] to delete history data from local storage.

Delete history data of 3 months ago
Delete history data of 6 months ago
Delete history data of 1 year ago
Delete history data of 2 years ago

(3) Channel A, H, B

- Channel A > displays temperature, AD1, or D01 according to sensor type
- Channel H > displays humidity, AD2, or D02 according to sensor type
- Channel B > displays battery level



Channel	G7-T2/TX/H2/H3	G7-AD	G7-TP	G7-MB	G7-D2
A	Temperature	AD1: 4-20mA	Temperature	Floating Point	D01: Open/Close
H	Humidity	AD2: 0-5V	Pressure	Integer	D02: Open/Close



High & Low Alarm Level lines can be dragged to different values for comparison or reference.



(4) Report Data Export

- Click [] button to export data of selected time range on report line chart
- Select the type of export data file




(5) Chart Style selection

When only one sensor is selected, press  button to select Chart, Column or Hi/Lo graph.



Hi/Lo Graph Report



(6) Button Function




- 1) Delete Station ID
- 2) Modify Station Name
- 3) Delete Local Storage
- 4) Setup Alarm Alert Properties

15. Day Night Display

(1) Day Night Mode select by Mouse Left Click




(2) Daylight Saving Time change by Mouse Right Click



16. Data Export

(A) Live Data Export

- Live Data of all registered base stations will be saved into local storage automatically
- Data will only be displayed and saved when running G7 MB Client on front end
- Max. 2 years of data will be kept in local storage
- Stored data can be exported to files in csv or SQLite format



Automatic Data Export

- (1) Select [Interval] – client software will export data of all registered base stations to files in interval
- (2) [Auto Export and send E-mail] allows data file sent to email address on Email Setup
- (3) [Enable] exports data of all registered base stations into user selectable folder in interval automatically

Manual Data Export


- (4) It allows user to export data of selected base station and period into a file

Example:

- User click [Enable] at 3:00pm and select “60 minutes” interval.
- G7 MB Client will start to export data at 3:00pm into files every 60 minute.
- At 9pm, there will be 6 data files between 3:00pm~9:00pm.

(B) History Data Export

- Live Data is received by G7 MB Client, and then saved into local storage automatically
- Data retrieved from local storage is History Data
- Download time will be long when time range is too wide



- (1) Select the base station and sensors in Report
- (2) Select the time range and start time
- (3) Select Channel A/H/B
- (4) Click [] button to export the data in csv or SQLite format

(C) Delete Stored Data

- (5) Click [] to delete history data from local storage

Delete history data of 3 months ago
 Delete history data of 6 months ago
 Delete history data of 1 year ago
 Delete history data of 2 years ago

17. Alarm Type


User will be alerted in following ways:

- G7 MB Client App (on screen and audio buzzer)
- Email sent from G7 MB Client


Alarm type:

- 1) Channel A: High Low Alarm - Temperature / Analog Sensor A01
- 2) Channel H: High Low Alarm - Humidity / Analog Sensor A02
- 3) Digital Alarm D01, D02
- 4) Sensor Battery Low Level [default: 2.5V]
- 5) Wireless Sensor Communication Loss or Sensor Not Configured Properly
- 6) Sensor Probe Defect
- 7) Sleep Mode Verification Alarm
- 8) Device Alarm
- 9) Data Resume Normal Level


(1) Sensor Alarm High




(2) Sensor Alarm Low




(3) Sensor Connection Loss / Sensor Not Configured




(4) Sensor Probe Defect or Disconnected




(5) Resume Normal Data




(6) Battery Low Level



(7) Digital Alarm





(8) Sleep Mode Verification Alarm



(9) Device Alarm

[Device Alarm] is the hardware alarm delivered from wireless sensor directly.

Device Alarm Level is configured in hardware by G7 Setup.



18. How user is alerted by alarm?



When soft alarm is triggered, user can be alerted by:


- (1) G7 Client – On Screen Display & Audio Buzzer
- (2) Alarm Email

(A) On Screen Display & Audio Buzzer on G7 MB Client


User will be alerted by:

- alert display
- audio buzzer
- alarm list





(B) Alarm Email Address – Alarm sent from G7 MB Client

- Automatic Data Export will be sent to the email address with [Data] enabled. Please refer to section [Data Export].
- Alarm Email will be sent to the email address with [Alarm] enabled.





(C) Alert Interval

- (1) Display and Email Alert will not be repeated within [Alert Interval] even when there is new alarm.
- (2) When alarm level is triggered, alarm will be activated only after [Alarm Delay] time.
- (3) Click [] icon > Display Alert Interval, Email Alert Interval and Alarm Delay Time



19. System Setting

Click [Menu]



(1) Automatic Page Jump Interval

- When page jump is selected, display interval can be selected.
- Auto page jump of groups (pages) of current base station
- Auto page jump of all registered base stations




(2) Sensor Sleep Mode Verification Alarm

- It alerts user when the sensor is not in sleep mode.
- When USB adaptor is connected, sensor cannot resume sleep mode.
- Battery saving is possible only in sleep mode.


(3) System File Folders

- \AutoExportFile Auto Data Export
- \BackupFile Manual Data Export
- \HistoryFile History Data Export in Report Mode
- \G7ClientBackupFile Configuration File Backup


(4) Configuration Backup



(5) Configuration Recovery after Login



(6) Configuration Recovery before Login




(7) Buzzer Alarm Duration

- Buzzer audio alarm will be turned off after the duration even when alarm is still triggered.

(8) Comparison Chart Interval

- Compare Chart should be configured properly.
- Chart Screen will be captured in interval automatically for record.
- Capture interval and storage folder location must be selected and saved.
- It works only when [Compare] mode is active.


(9) Check the Product Key and License Key




20. G7 Viewer

- G7 Viewer is designed for normal user or operator in daily monitoring. It does not provide setup but view only.
- G7 MB Client creates Configuration Backup File.
- G7 Viewer makes use of configuration setting by recovering the configuration backup file. Configuration setup or change is not allowed in G7 Viewer, except “Data Export Save Path”.
- Make sure that G7 Viewer [Direct Mode] computer has the IP same as server IP configured in G7-BS.


(1) Search “G7 Viewer” in keywords, and click [Get] to install




(2) Open [G7 Viewer], and Click [Recovery] icon




(3) Select the G7 MB Client Backup File folder



(4) After “Recovery Success”, G7 Viewer must be restarted.






(5) Restart “G7 Viewer”



21. G7 Client for Android Phone

Search keyword "G7 Client" in Play Store.


- Refer the Server IP and Port of Base Station Setup



- Run G7 Client, Click [Login Setup], Select [Direct Mode]


- Enter the Port and Product Key

- Click [Login]





Click [Login] to connect
base stations

- Base Stations will be added to the list once connection is made successfully.
- User can modify station name and UTC of each base station.
- It is recommended to activate/deactivate sensors in order to avoid too many display pages.




- When base stations are located in different time zone, UTC must be setup correctly in order to display the data in correct local time at Client Phone.
- Disable [Modify Disconnect Alarm] when sensors are manually disconnected for maintenance
- Click [Setup] to setup the temperature unit, alarm sound and sensor sleep mode alarm.








Green: Normal
Red: High Alarm
Yellow: Low Alarm




Drag Right/Left:
Switch to next channel




Tap on alarm:
Instant jump to live view of alarm channel




Tap & Hold on Meter
Setup Alarm Level & Display Range




Drag Up for Full Alarm List
Alert Interval: 1 min default



[Digital Alarm Input]




Tap & Hold on Meter
Setup Digital Alarm



[Live]


Base Station selected on last page (e.g. Meter) will be displayed on [Live] page.



Tap to display data and time

- Live Data will be saved into local storage of mobile phone (max. 180 days)
- Report retrieves data from phone local storage
- Inquiry of maximum 10000 records


[Report]



22. G7 Client for iPhone

Search keyword “G7 Client” in App Store.


- Refer the Server IP and Port of Base Station Setup




- Run G7 Client, Select [Direct Mode]

- Enter the Port and Product Key


- Click [Login]



- Base Station ID of incoming data will be added automatically (max. 20 base stations)
- User can modify station name and UTC of each base station.
- It is recommended to activate/deactivate sensors in order to avoid too many display pages.



- When base stations are located in different time zone, UTC must be setup correctly in order to display the data in correct local time at Client iPhone.
- Cancel [Modify Disconnect Alarm] when sensors are manually disconnected for maintenance.
- Click [Setup] to setup the temperature unit, alarm sound and sensor sleep mode alarm.



Swap Up/Down: Display or Hide the Chart

Tap & Hold to modify Channel Name

[Data]

Station: 00004 - machine
Last Time: 2018-05-05 08:36:00

27.27	62.35	24.75
S01 - humidity	S02 - temp2	
S03 - switch	S04 - door	
Channel A	Channel H	Channel B

40.000-----

-20.00-----

04 08:38:00 S02 - temp2 05 08:37:00

1 Week 1 Day

Swap Right/Left: Display Channel [A & H] or B

Drag Right/Left: Switch to next channel group (S01-S08, S09-S16, S17-S21 ...)

Go to [Chart Select]

[Data]

Station: 00004 - machine
Last Time: 2018-05-04 16:13:00

25.89	57.46	23.81
S01 - humidity	S02 - temp2	
S03 - switch	S04 - door	
-22.7	25.25	
S05 - freezer	S06 - temp6	
-24.0	23.56	
S07 - cold storage	S08 - temp8	

**Green: Normal
Red: High Alarm
Yellow: Low Alarm**

Swap Up/Down: Display or Hide the Chart

Tap & Hold to modify Channel Name

[Data]

Station: 00004 - machine
Last Time: 2018-05-04 16:11:00

Modify Channel Name

temp2

Cancel OK

1 2 3 4 5 6 7 8 9 0
- / : ; () \$ & @ " #+= . , ? ! ' ABC space return

[Chart Select]


< Chart Select

Meter	Data
Live	Report

Drag Right/Left:

Switch to next channel



[Meter]



Tap on alarm:

Instant jump to live view of alarm channel

[Alarm]



Tap & Hold on Meter

Setup Alarm Level & Display Range

[Range Setting]

Temperature:

- AD01 Max Value: 125.00
- AD01 Min Value: -55.00
- AD01 Higher Alarm Value: 80.000
- AD01 High Alarm Value: 60.000
- AD01 Low Alarm Value: -15.00
- AD01 Lower Alarm Value: -20.00

Humidity:

- AD02 Max Value: 100.00
- AD02 Min Value: 0.0000
- AD02 Higher Alarm Value: 80.000
- AD02 High Alarm Value: 60.000
- AD02 Low Alarm Value: 15.000
- AD02 Lower Alarm Value: 0.0000


Drag Up for Full Alarm List

Alert Interval: 1 min default

[Full Alarm List]

Alarm List	
2018-05-05 09:07:00	00004 - S07
Temp Low Alarm 2, -20.10 Lower than -20.0	
2018-05-05 09:07:00	00004 - S02
Temp High Alarm 1, 35.620 Higher than 35.00	
2018-05-04 19:06:58	00004 - S01
Resume Normal Data A01:27.27 H01:74.07 B01:03000100	
2018-05-05 09:06:00	00004 - S07
Temp Low Alarm 2, -20.10 Lower than -20.0	
2018-05-05 09:06:00	00004 - S02
Temp High Alarm 2, 41.560 Higher than 38.00	
2018-05-05 09:06:00	00004 - S01
Humidity High Alarm 2, 92.620 Higher than 90.00	
2018-05-05 09:05:00	00004 - S07

[Digital Alarm Input]

Tap & Hold on Meter
Setup Digital Alarm



< Close Triggered Alarm Setup

D01 Enable Alarm:

D02 Enable Alarm:



[Live]

Base Station selected on last page (e.g. Meter) will be displayed on [Live] page.



Tap to display data and time

- Live Data will be saved into local storage of mobile phone (max. 180 days)
- Report retrieves data from phone local storage
- Inquiry of maximum 10000 records



23. G7 Client for iPad

Search keyword “G7 Client” in App Store.

- Refer the Server IP and Port of base station setup
- Select [Direct Mode], enter “Port No.” same as G7-BS Setup
- Click [Login]



G7 Client for iPad
Easemind Technology Ltd.
Not Enough Ratings 4+ Age

Local Port 6900

IP Address 192.168.0.70

Server IP / Domain 192.168.0.70
Server Port 6900


IP Address 192.168.0.70

1. Meter View

After Login, connected base station ID will be automatically added.

Login - Logout and Exit
System - System Setting
Cancel - Resume Main Screen

- Double Tap on main meter
- Drag the alarm level lines to configure the alarm levels
- Change and save alarm setting



Select Base Station




- 1) Delete Station
- 2) Modify Station Name
- 3) Setup Alarm Alert Parameters
- 4) Start Automatic Page Jump of selected base station (only in meter, compare display modes)

- Double Tap on main meter
- Drag the alarm level lines to configure the alarm levels
- Change and save alarm setting



Please refer the operation, setup and control for iPad to Windows 10 version.


2. HMI View




3. Data View

Meter	HMI	Data	Compare	Report				
24.52 55.51 S01 - 01	23.12 S02 - 02	● ● S03 - 03	● ● S04 - 04	-19.0 S05 - 05	22.93 S06 - 06	-15.0 S07 - 07	22.81 S08 - 08	
23.22 55.52 S09 - 09	37.30 S10 - 10	23.20 56.65 S11 - 11	22.81 S12 - 12	23.18 S13 - 13	23.18 S14 - 14	23.00 S15 - 15	23.00 S16 - 16	
23.00 S17 - 17	22.81 S18 - 18	23.12 S19 - 19	23.18 S20 - 20	● ● S21 - 21	23.12 S22 - 22	23.25 S23 - 23	22.93 S24 - 24	
S25 - 25	S26 - 26	S27 - 27	S28 - 28	S29 - 29	S30 - 30	S31 - 31	S32 - 32	
S33 - 33	S34 - 34	S35 - 35	S36 - 36	S37 - 37	S38 - 38	S39 - 39	S40 - 40	
S41 - 41	S42 - 42	S43 - 43	S44 - 44	S45 - 45	S46 - 46	S47 - 47	S48 - 48	
S49 - 49	S50 - 50	S51 - 51	S52 - 52	S53 - 53	S54 - 54	S55 - 55	S56 - 56	
S57 - 57	S58 - 58	S59 - 59	S60 - 60	S61 - 61	S62 - 62	S63 - 63	S64 - 64	
Sensor				Battery				
Base Station 00003 - Machine	✖ ⚡ ⚙			● Direct Mode	2018-04-27 16:18:00			
Soft Alarm 2018-04-27 16:18:00 Station: 00003 - Machine S21 - 21, D01, Alarm Type: Open/Close Alarm, Close Triggered Alarm								

4. Compare View



5. Report View



24. Safety and Regulatory Notice

All applicable regulatory compliance statements, product certification markings, and safety and electromagnetic compatibility (EMC) standards and regulations the Data Logger is compliant with.

European Union Declaration of Conformity

Statement

We, Easemind, declare under our sole responsibility that the product G7 & G8 are in conformity with all applicable essential requirements necessary for CE marking, following the provisions of the European Council Directives 2004/108/EC (EMC Directive) and 2006/95/EC (Low Voltage Directive).



The product is properly CE marked demonstrating this conformity and is for distribution within all member states of the EU with no restrictions.

This product follows the provisions of the European Directives 2004/108/EC and 2006/95/EC.

Customer Support Links

View or download product support information from website:

<http://www.easemind.net>

or email contact at: email@easemind.net

25. Manufacturer's Disclaimer Statement

The information in this document is subject to change without notice and does not represent a commitment on the part of the vendor. No warranty or representation, either expressed or implied, is made with respect to the quality, accuracy or fitness for any particular purpose of this document. The manufacturer reserves the right to make changes to the content of this document and/or the products associated with it any time without obligation to notify any person or organization of such changes. In no event will the manufacturer be liable for direct, indirect, special, incidental or consequential damages arising out of the use or inability to use this product or documentation, even if advised of the possibility of such damages. This document contains materials protected by copyright. All rights are reserved. No part of this manual may be reproduced or transmitted in any form, by any means or for any purpose without expressed written consent of its authors. Product names appearing in this document are mentioned of identification purposes only. All trademarks, product names or brand names appearing in this document are registered property of their respective owners.

Trademarks

“G7 Client” & “G7 MB Client” are the registered trademark of Easemind Technology Ltd.