

G7 Wireless Sensor System

TCP Modbus

Version 2.3.2

Hardware Support:

G7-BS [V1.2.2 / 2.2.2 / 2.3.1]

X7-BS [V1.2.2 / 2.2.2]

❖ In TCP Client mode


1. G7-BS base station will initiate the data upload to central server on schedule or alarm triggered. Server only needs to wait for the data incoming from G7 Base Station.
2. Under normal operation, G7 Wireless Sensor System works in TCP Client mode.
3. G7 Setup Software will turn G7 Base Station as TCP Client mode **by default**.

❖ In TCP Server mode (TCP Modbus)


1. Third party software (e.g. BMS) will send command to G7-BS base station asking for the data.
2. G7-BS Base Station will not initiate any data upload automatically.

- ❖ “G7 TCP Switch” is a software tool to switch G7-BS Base Station between TCP Server Mode and TCP Client Mode.

(1) Disable all the alarms in wireless sensor setup




(2) Configure base station as "Fixed IP", and then exit Setup Software



(3) Run “TCP Switch”

Base Station is in TCP Client mode by default.

1. Select the computer IP address (when there are two or more networks connected)
2. Select base station hardware version (V1 or V2)
3. Select the base station
4. Click [TCP Server Mode] button



i G7 base station will turn back to TCP Client mode once user configures the base station by G7 Setup.

Base Station is now in TCP **Server** mode.

- Device Modbus Address = Last 2 digits of Station ID + "0"
- Station ID = 022**23**
- Device Modbus Address = 230

The screenshot shows the G7 TCP Switch software interface. At the top, it displays 'G7 TCP Switch' and 'Version 2.3.1'. Below this, there are dropdown menus for 'V2.x.x' and '192.168.11.61'. A warning message reads: 'Try to disable firewall when no base station is found or connection fails'. The main area contains a table with the following data:

Status	MAC Address	IP Properties	Station IP	Station Port	Subnet	Gateway	Mode	Modbus Address
●	9C:A5:25:8E:49:D5	Dynamic IP	192.168.11.151	7000			TCP SERVER	010
●	9C:A5:25:A3:A8:29	Dynamic IP	192.168.11.236	7000			TCP SERVER	040
●	9C:A5:25:B7:AD:B9	Fixed IP	192.168.11.204	7000	192.168.11.1	255.255.255.0	TCP SERVER	230
●	9C:A5:25:A3:A7:D1	Dynamic IP	192.168.11.78	7000			TCP SERVER	200

A red box highlights the row for Station IP 192.168.11.204, Subnet 192.168.11.1, Gateway 255.255.255.0, Mode TCP SERVER, and Modbus Address 230. A dialog box in the foreground displays 'Change Mode Success' with an 'OK' button. At the bottom, there are buttons for 'TCP Server Mode' and 'TCP Client Mode', and an 'Upload Interval' dropdown menu.

- Write down its Modbus Address, IP address and port number for future TCP Modbus access


IP Address: 192.168.11.204

Port: 7000

Modbus Address: 230

Base Station IP properties modification

- Select the base station
- Double Click “Mouse Right Button”
- Network Properties can be modified
- Base Station IP should be configured as Fixed IP for TCP Server Mode operation



(4) Modbus Data Register Address

After G7 Base Station is configured as TCP Server mode, it will not initiate any data upload.

In TCP Server mode, ModScan software or SCADA system will send command to G7 Base Station asking for the data.

G7 Modbus Address Table



- Run the “G7 TCP Switch” to change G7 Base Station into TCP Server Mode.
- Make use of Modbus scanner or third party SCADA to read the data from data logger.



Device Modbus Address = Last 2 digits of Station ID + “0”

	Data Register Address				Data Register Address		
	A Value	H Value	Battery Voltage		A Value	H Value	Battery Voltage
Sensor ID = 1	40001	40003	40005	Sensor ID = 33	40193	40195	40197
Sensor ID = 2	40007	40009	40011	Sensor ID = 34	40199	40201	40203
Sensor ID = 3	40013	40015	40017	Sensor ID = 35	40205	40207	40209
Sensor ID = 4	40019	40021	40023	Sensor ID = 36	40211	40213	40215
Sensor ID = 5	40025	40027	40029	Sensor ID = 37	40217	40219	40221
Sensor ID = 6	40031	40033	40035	Sensor ID = 38	40223	40225	40227
Sensor ID = 7	40037	40039	40041	Sensor ID = 39	40229	40231	40233
Sensor ID = 8	40043	40045	40047	Sensor ID = 40	40235	40237	40239
Sensor ID = 9	40049	40051	40053	Sensor ID = 41	40241	40243	40245
Sensor ID = 10	40055	40057	40059	Sensor ID = 42	40247	40249	40251
Sensor ID = 11	40061	40063	40065	Sensor ID = 43	40253	40255	40257
Sensor ID = 12	40067	40069	40071	Sensor ID = 44	40259	40261	40263
Sensor ID = 13	40073	40075	40077	Sensor ID = 45	40265	40267	40269
Sensor ID = 14	40079	40081	40083	Sensor ID = 46	40271	40273	40275
Sensor ID = 15	40085	40087	40089	Sensor ID = 47	40277	40279	40281
Sensor ID = 16	40091	40093	40095	Sensor ID = 48	40283	40285	40287
Sensor ID = 17	40097	40099	40101	Sensor ID = 49	40289	40291	40293
Sensor ID = 18	40103	40105	40107	Sensor ID = 50	40295	40297	40299
Sensor ID = 19	40109	40111	40113	Sensor ID = 51	40301	40303	40305
Sensor ID = 20	40115	40117	40119	Sensor ID = 52	40307	40309	40311
Sensor ID = 21	40121	40123	40125	Sensor ID = 53	40313	40315	40317
Sensor ID = 22	40127	40129	40131	Sensor ID = 54	40319	40321	40323
Sensor ID = 23	40133	40135	40137	Sensor ID = 55	40325	40327	40329
Sensor ID = 24	40139	40141	40143	Sensor ID = 56	40331	40333	40335
Sensor ID = 25	40145	40147	40149	Sensor ID = 57	40337	40339	40341
Sensor ID = 26	40151	40153	40155	Sensor ID = 58	40343	40345	40347
Sensor ID = 27	40157	40159	40161	Sensor ID = 59	40349	40351	40353
Sensor ID = 28	40163	40165	40167	Sensor ID = 60	40355	40357	40359
Sensor ID = 29	40169	40171	40173	Sensor ID = 61	40361	40363	40365
Sensor ID = 30	40175	40177	40179	Sensor ID = 62	40367	40369	40371
Sensor ID = 31	40181	40183	40185	Sensor ID = 63	40373	40375	40377
Sensor ID = 32	40187	40189	40191	Sensor ID = 64	40379	40381	40383

Data Field	G7-T2/TX/H2/H3	G7-AD	G7-D2	G7-TP	G7-MB
A	Temperature	AD1: 4-20mA	D01: Open/Close	Temperature	Modbus Analog
H	Humidity	AD2: 0-5V	D02: Open/Close	Pressure	Modbus Pulse
B	Battery Voltage				

(5) Run [ModScan32]






[Example 1]

G7-BS Base Station ID: 00223

Number of Sensors enabled and connected: 8




Modbus Device Address = Station ID

	Data Register Address		
	Temperature	Humidity	Battery Voltage
Sensor ID = 1	40001	40003	40005
Sensor ID = 2	40007	40009	40011
Sensor ID = 3	40013	40015	40017
Sensor ID = 4	40019	40021	40023
Sensor ID = 5	40025	40027	40029
Sensor ID = 6	40031	40033	40035
Sensor ID = 7	40037	40039	40041
Sensor ID = 8	40043	40045	40047
Sensor ID = 9	40049	40051	40053
Sensor ID = 10	40055	40057	40059

[Example 1]

G7-BS Base Station ID: 00223

Number of Sensors enabled and connected: 8




◆ Sensor: G7-D2

- Data Field A: 00001 Alarm On
- Data Field H: 00000 Alarm Off

[Example 2]


G7-BS Base Station ID: 00008

Number of Sensors enabled and connected: 8



Modbus Device Address = Station ID			
	Data Register Address		
	Temperature	Humidity	Battery Voltage
Sensor ID = 1	40001	40003	40005
Sensor ID = 2	40007	40009	40011
Sensor ID = 3	40013	40015	40017
Sensor ID = 4	40019	40021	40023
Sensor ID = 5	40025	40027	40029
Sensor ID = 6	40031	40033	40035
Sensor ID = 7	40037	40039	40041
Sensor ID = 8	40043	40045	40047
Sensor ID = 9	40049	40051	40053
Sensor ID = 10	40055	40057	40059

(6) Revert to TCP Client Mode



Select the base station and upload interval, and Click [TCP Client Mode]

